

Haier

Parts Lists

Forward Series

Rev. Feb. 2017

HSU09VHJ(DB)-G / HSU09VHJ(DB)-W

HSU12VHJ(DB)-G / HSU12VHJ(DB)-W

HSU18VHJ(DB)-G / HSU18VHJ(DB)-W

HSU24VHJ(DB)-G / HSU24VHJ(DB)-W

HaierAmerica

1800 Valley Road
Wayne, NJ 07470
Tel +973.617.1800
www.Haier.com

Revision History

Rev. Feb. 2017 - Edition release.


Haier

Parts List

Forward Series

HSU09VHJ(DB)-G


Exploded View



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
1	A0010201183A	INLET GRILLE PANEL	1
2	A0010810194B	CASING	1
3	A0010201344	AIR FILTER (L)	1
4	A0010201354	AIR FILTER (R)	1
5	A0010708060	EVAPORATOR ASSY.	1
6	A0010202415A	CROSS FLOW FAN	1
7	A0010403935	NEGATIVE ION GENERATOR	1
8	A0010807698E	FRAME ASSY.	1
9	A001A1232082A	TOP GRILLE	1
10	A0010101275	MOUNTING PLATE	1
11	A001A0900011	DRAIN HOSE	1
12	A0010201198	DRAIN PAN	1
13	A001A3000072E	STEPPER MOTOR	1
14	A0010201351C	BLADE	1
15	A0010404233	INDOOR MOTOR	1
16	A001A1431366E	MOTOR COVER	1
17	A0010201255	DISPLAY BOX	1
18	A0011800033C	DISPLAY PANEL	1
19	A0010201343A	COVER FOR DISPLAY BOX	1
20	A0010201341	SUPPORT	1
21	A0010204784	SERVICE COVER	1
22	A0010101879	SERVICE COVER	1
23	A0010201180	SERVICE COVER	1
24	A0010100619	CONTROL BOX COVER	1
25	A0011800195B	INDOOR PCB	1
26	A0010201181	CONTROL BOX	1
27	A0010810069	CONTROL BOX BACK GUARD ASSY	1
28	A0010403863	TERMINAL BLOCK	1
29	A001A3900059E	SENSOR	1
30	A0014500001	TRANSFORMER	1
31	A0010849078	BEARING	1
32	A0010600367	SCREWS ASSY.	1
33	A0010401363	REMOTE CONTROL	1
34	A001A1434039	DRAIN HOSE	1
35	A0010805043	FILTER AIR PURIFYING	1
36	A001A4600001	BATTERY	2
37	A001A1433307	GUARD RING	1
38	A001A1431038	PIPE CLIP	1
39	A001A1431368	PIPING SUPPORT	1

Exploded View



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
40/41	A0010821324	OUTLET GRILL & CASING	1
42	A0010203662A	AXIAL FAN	1
43	A0010403322A	OUTDOOR MOTOR	1
44	A0010100418A	BRACKET FOR FAN MOTOR	1
45	A0010710117	CONDENSER ASSY.	1
46	A0010870316	BACK GUARD BOARD ASSY.	1
47	A0010870315	BEAM ASSY.	1
48	A0010870314	FACING BAR ASSY.	1
49	A0010870321	TOP COVER	1
50	A001A3900055	PIPE SENSOR	1
51	A0010708048	4-WAY VALVE ASSY.	1
52	A0010720125	ELECTRONIC EXPANSION VALVE	1
53	A0010203648	SOUND INSULATING CUSHION	1
54	A0010705988	3-WAY VALVE	1
55	A0010705987	2-WAY VALVE	1
56	A0010706492	COMPRESSOR	1
57	A0010201259	CUSHION	1
58	A0010205959	ELECTRICAL BOX	1
59	A0011800208	OUTDOOR PCB	1
60	A0011800052	POWER MODULE	1
61	A0010101970	PARTITION BOARD ASSY.	1
62	A0010400268	REACTOR	1
63	A001A1101014	BOTTOM PANEL ASSY.	1
64	A0010100910	SERVICE COVER	1
65	A0010100911	WIRE COVER	1
66	A0010710209	DISCHARGING TUBE	1
67	A0010710210	SUCTION TUBE	1
68	A001A3900056	COMPRESSOR TEMPERATURE SENSOR	1
69	A001A3900062E	SUCTION TEMP. SENSOR	1
70	A001A3800082E	AMBIENT TEMPERATURE SENSOR	1
71	A0010401190	OUTDOOR WIRE BUNCH	1
72	A0010400649	TERMINAL BLOCK	1
73	A0010400655B	RADIATOR	1
74	A0010600354	FLANGE NUT	1


Haier

Parts List

Forward Series

HSU12VHJ(DB)-G


Exploded View



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
1	A0010202431	FRONT PANEL	1
2	A0010201352	UNLOCKING	1
3	A0010201341	SUPPORT	1
4	A0011800033C	DISPLAY PANEL	1
5	A0010201343A	COVER FOR DISPLAY BOX	1
6	A0010201255	DISPLAY BOX	1
7	A0010202411	AIR FILTER (L)	1
8	A0010202432	AIR FILTER (R)	1
9	A0010202446	FRONT PANEL	1
10	A0010709496	EVAPORATOR ASSY.	1
11	A0010202227	CROSS FLOW FAN	1
12	A0010849078	BEARING	1
13	A0010202418	BLADE	1
14	A0010204993	DRAIN PAN	1
15	A001A3100143	NEGATIVE ION GENERATOR	1
16	A001A1431678-R	COVER FOR NEGATIVE ION GENERATOR	1
17	A001A0100276A	FRAME ASSY.	1
18	A0010101275	MOUNTING PLATE	1
19	A001A0900011	DRAIN HOSE	1
20	A001A3000072E	STEPPER MOTOR	1
21	A001A3000088E	INDOOR MOTOR	1
22	A001A1431372E	MOTOR COVER	1
23	A0010202387	CABLE CLAMP	1
24	A0010202398	ELECTRICAL BOX	1
25	A0010100882	BOARD FOR ELECTRICAL BOX	1
26	A0010811775	BOARD FOR ELECTRICAL BOX	1
27	A0010100917	BOARD FOR ELECTRICAL BOX	1
28	A0010202397	BOARD FOR ELECTRICAL BOX	1
29	A001A3900059E	SENSOR	1
30	A0010100918	BOARD FOR ELECTRICAL BOX	1
31	A0010202395	BOARD FOR ELECTRICAL BOX	1
32	A0011800195B	INDOOR PCB	1
33	A0010403863	TERMINAL BLOCK	1
34	A0014500001	TRANSFORMER	1
35	A0010101901	WIRE NETTING	1
36	A001A1431038	PIPE CLIP	1
37	A001A4600001	BATTERY	2
38	A0010401363	REMOTE CONTROL	1
39	A0010600367	SCREWS ASSY.	1
40	A0010805043	FILTER AIR PURIFYING	1
41	A001A1434039	DRAIN HOSE	1
42	A001A1433307	GUARD RING	1
43	A001A1431368	PIPING SUPPORT	1


Exploded View



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
44	A001A1436043A	OUTLET GRILL	1
45	A0010101399	CASE	1
46	A0010203662A	AXIAL FAN	1
47	A0010403322A	OUTDOOR MOTOR	1
48	A0010100418A	BRACKET FOR FAN MOTOR	1
49	A0010708097	CONDENSER ASSY.	1
50	A0010870316	BACK GUARD BOARD ASSY.	1
51	A0010870315	BEAM ASSY.	1
52	A0010870314	FACING BAR ASSY.	1
53	A0010870321	TOP COVER	1
54	A001A3900055	PIPE SENSOR	1
55	A0010708048	4-WAY VALVE ASSY.	1
56	A0010705213	ELECTRONIC EXPANSION VALVE ASSY	1
57	A0010709087	CAPILLARY ASSY.	1
58	A0010203648	SOUND INSULATING CUSHION	1
59	A0010705988	3-WAY VALVE	1
60	A0010705987	2-WAY VALVE	1
61	A0010706492	COMPRESSOR	1
62	A0010201259	CUSHION	1
63	A0010205959	ELECTRICAL BOX	1
64	A0011800208	OUTDOOR PCB	1
65	A0011800052	POWER MODULE	1
66	A0010101970	PARTITION BOARD ASSY.	1
67	A0010400268	REACTOR	1
68	A001A1101014	BOTTOM PANEL ASSY.	1
69	A0010100910	SERVICE COVER	1
70	A0010100911	WIRE COVER	1
71	A0010702042	DISCHARGE TUBE	1
72	A0010702036	SUCTION TUBE	1
73	A001A3900056	COMPRESSOR TEMPERATURE SENSOR	1
74	A001A3900062E	SUCTION TEMP. SENSOR	1
75	A001A3800082E	AMBIENT TEMPERATURE SENSOR	1
76	A0010401190	OUTDOOR WIRE BUNCH	1
77	A0010400649	TERMINAL BLOCK	1
78	A0010400655B	RADIATOR	1
79	A0010600354	FLANGE NUT	1


Exploded View



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
1	A0010205480	DISPLAY PANEL	1
2	A0010205851	PANEL	1
3	A0010205854	AIR FILTER 2	1
4	A0010205855	AIR FILTER 1	1
5	A0010205856	BOLT COVER	4
6	A0010205853	TOP BLADE	1
7	A0010205852	UNDER BLADE	1
8	A0010205850	CASING	1
9	A0010205357	DISPLAY BOX COVER	1
10	A0010404071C	DISPLAY PANEL	1
11	A0010205356	DISPLAY BOX	1
12	A0010818921	DRAIN PAN	1
13	A0010101954	WIRE NETTING	1
14	A0010709640	EVAPORATOR ASSY.	1
15	A0010205866	CROSS FLOW FAN	1
16	A0010849078	BEARING	1
17	A0010818922	FRAME ASSY.	1
18	A0010101949	MOUNTING PLATE	1
19	A0010205355	SERVICE COVER	1
20	A0010404101	INDOOR MOTOR	1
21	A0010205857	MOTOR COVER	1
22	A0010205741A	ELECTRICAL BOX	1
23	A0011800001A	INDOOR PCB	1
24	A0010101908	ELECTRICAL BOX PROTECTOR BOARD	1
25	A0010403863	TERMINAL BLOCK	1
26	A0010205742A	ELECTRICAL BOX COVER	1
27	A0010101907	ELECTRICAL BOX COVER	1
28	A0010205864	WIRE COVER	1
29	A001A3900059E	SENSOR	1
30	A0010101956	FIXITY	1
31	A0010402433A	STEPPER MOTOR	1
32	A0010400337E	NEGATIVE ION GENERATOR	1
33	A001A1431038	PIPE CLIP	1
34	A001A4600001	BATTERY	2
35	A001A1434039	DRAIN HOSE	1
36	A001A1433307	GUARD RING	1
37	A0010805043	FILTER AIR PURIFYING	1
38	A0010401363	REMOTE CONTROL	1
39	A0010600367	SCREWS ASSY.	1

Exploded View





Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
40	A0010806977B	CASING ASSY.	1
41	A0010203662	AXIAL FAN	1
42	A0010403322A	OUTDOOR MOTOR	1
43	A0010101533	BRACKET	1
44	A0010710287	CONDENSER ASSY.	1
45	A0010870168	BACK GUARD BOARD ASSY.	1
46	A0010870315	BEAM ASSY.	1
47	A0010870165	FACING BAR ASSY.	1
48	A0010870321	TOP COVER	1
49	A001A3900055	PIPE SENSOR	1
50	A0010708049	4-WAY VALVE ASSY.	1
51	A0010706269E	ELECTRONIC EXPANSION VALVE	1
52	A0010708740	CAPILLARY ASSY.	1
53	A0010705989	3-WAY VALVE	1
54	A0010705987	2-WAY VALVE	1
55	A0150701215	COMPRESSOR	1
56	A001A17621544	CUSHION	1
57	A0010205959	ELECTRICAL BOX	1
58	A0011800208A	OUTDOOR PCB	1
59	A0011800052K	POWER MODULE	1
60	A0010101971	PARTITION BOARD ASSY.	1
61	A0010400268	REACTOR	1
62	A001A1101014	BOTTOM PANEL ASSY.	1
63	A0010100910	SERVICE COVER	1
64	A0010100911	WIRE COVER	1
65	A0010710044	DISCHARGING TUBE	1
66	A0010709752	SUCTION TUBE	1
67	A001A3900056	COMPRESSOR TEMPERATURE SENSOR	1
68	A001A3800082E	AMBIENT TEMPERATURE SENSOR	1
69	A001A3900062E	SUCTION TEMP. SENSOR	1
70	A0010401190	OUTDOOR WIRE BUNCH	1
71	A0010400649	TERMINAL BLOCK	1
72	A0010400655B	RADIATOR	1
73	A0010600354	FLANGE NUT	1

Exploded View


Edition: 2009/08/21



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
1	A0010205480	DISPLAY PANEL	1
2	A0010205851	PANEL	1
3	A0010205855	AIR FILTER 1	1
4	A0010205854	AIR FILTER 2	1
5	A0010205856	BOLT COVER	4
6	A0010205853	TOP BLADE	1
7	A0010205852	UNDER BLADE	1
8	A0010205850	CASING	1
9	A0010818921	DRAIN PAN	1
10	A0010712789	EVAPORATOR ASSY.	1
11	A0010819169	BEARING COVER ASSY.	1
12	A0010849078	BEARING	1
13	A0010205866	CROSS FLOW FAN	1
14	A0010818922	FRAME ASSY.	1
15	A0010101949	MOUNTING PLATE	1
16	A0010205355	SERVICE COVER	1
17	A0010819168	MOTOR COVER	1
18	A0010404101	INDOOR MOTOR	1
19	A0010819168	MOTOR COVER	1
20	A0010205741A	ELECTRICAL BOX	1
21	A0010101908	ELECTRICAL BOX PROTECTOR BOARD	1
22	A0010101907	ELECTRICAL BOX COVER	1
23	A0010403863	TERMINAL BLOCK	1
24	A0010205742A	ELECTRICAL BOX COVER	1
25	A0010205864	WIRE COVER	1
26	A0010402433A	STEPPER MOTOR	1
27	A0010205357	DISPLAY BOX COVER	1
28	A0010404071C	DISPLAY PANEL	1
29	A0010205356	DISPLAY BOX	1
30	A0010201352	UNLOCKING	1
31	A001A3900059E	SENSOR	1
32	A001A1431038	PIPE CLIP	2
33	A0010400337E	NEGATIVE ION GENERATOR	1
34	A0011800001A	INDOOR PCB	1
35	A0010204945	DRAIN HOSE	1
36	A001A4600001	BATTERY	2
37	A0010600367	SCREWS ASSY.	1
38	A0010805043	AIR PURIFYING	2
39	A001A1434039	DRAIN HOSE	1
40	A001A1433307	GUARD RING	1
41	A0010401363	REMOTE CONTROL	1

Exploded View



Parts List

Exploded View Number	Spare Part Number	Spare Part Name	Part Consumption Qty
42	A0010807417	CASING	1
43	A0010600355	FLANGE NUT	1
44	A0010204485	AXIAL FAN	1
45	A0010401087	OUTDOOR MOTOR	1
46	A0010102239	BRACKET FOR FAN MOTOR	1
47	A0010709009	CONDENSER ASSY.	1
48	A0010870155	SIDE PLATE (L) ASSY.	1
49	A001A1436182	HANDLE	1
50	A0010881122	TOP COVER ASSY.	1
50	A001A1101108	TOP PANEL	1
51	A0010101448	SIDE PANEL	1
52	A001A1301415	BACK GRILLE	1
53	A0010813450	PARTITION BOARD ASSY.	1
54	A0010870145	TERMINAL COVER ASSY.	1
55	A0010870187	TERMINAL COVER ASSY.	1
56	A0010201827	CORK	1
57	A0010813451	ELECTRIC BOX	1
58	A001A4000082	TERMINAL BLOCK	1
59	A001A4000105	TERMINAL BLOCK	1
60	A0011800179G	OUTDOOR PCB BOARD	1
61	A0010400647	RADIATOR	1
62	A0010400352C	POWER MODULE	1
63	A0010401130	OUTDOOR WIRE BUNCH	1
64	A001A3900056	COMPRESSOR TEMPERATURE SENSOR	1
65	A001A3800082E	AMBIENT TEMPERATURE SENSOR	1
66	A001A3900055	PIPE SENSOR	1
67	A0150701215	COMPRESSOR	1
68	A001A1101110	BOTTOM PLATE	1
69	A001A1301127	VALVE BOARD	1
70	A0010708017	2-WAY STOP VALVE	1
71	A0010758715	3-WAY STOP VALVE	1
72	A0010712462	DISCHARGING TUBE ASSY.	1
73	A0010712463	SUCTION TUBE	1
74	A0010708049	4-WAY VALVE ASSY.	1
75	A0010722292	ELECTRONIC EXPANSION VALVE	1